



Getting Started

Get Started with your Fujitsu STYLISTIC® Q572 Tablet PC

This guide will lead you through the start-up process for your new LIFEBOOK tablet and will also provide some valuable tips. To learn about all the exciting features that your new LIFEBOOK tablet has to offer, please see the User's Guide that can be accessed after completing the start-up procedure.

ENGLISH



This convenient guide will lead you through the start-up process and will also offer some valuable tips.

What's in the Box


Check to see that all of the following items are in the box:

- STYLISTIC Hybrid Tablet
- Lithium Polymer battery, pre-installed
- AC adapter with power cord


Depending upon your configuration, the following items may also be shipped with your tablet:

- Microsoft Product Identifier (bi-fold paper contains Microsoft Office product key for activation)


Controls, Connectors, and Access Points




LEFT PANEL






RIGHT PANEL



BOTTOM PANEL





Initial Start Up

1. Install the Pen Battery

- Remove the cap from the end of the pen and insert a AAAA-battery positive end first. Reinstall the pen cap.

2. Attach the Pen Tether

- Take the smaller loop on the pen tether and insert it about half way into the slot in the pen cap. Thread the tether through the end of the loop extending through the slot. Now take the larger loop on the tether and insert in the same manner through the attachment point on the right side of your tablet. Thread the pen through the end of the loop extending through the attachment point.

3. Connect AC Power

- Plug the power cord into the AC adapter.
- Plug the AC adapter into your STYLISTIC Tablet PC.
- Connect the power cord to an electrical outlet.

4. Booting the System

- We strongly recommend that you do not attach any external devices until you have gone through the initial power on sequence.
- Slide and release the Power/Suspend Resume switch.
- Your tablet is now on and the battery is being charged.
- When you turn on your tablet for the first time, it will display a Fujitsu logo on the screen. If you do nothing the system will load the operating system, and then the Windows Welcome will begin.

5. Starting Windows® for the First Time

- After you boot up the system the first time and follow the instructions on the screen, you will eventually come to the Welcome window. After the Welcome window appears, the screen will black out for up to several minutes. This is normal. **DO NOT ATTEMPT TO POWER DOWN THE SYSTEM AT THIS POINT.** While the screen is blacked out, your system configuration is being set up and the necessary files are being installed.
- During the course of the first start up, you will need to read and accept the End User License Agreements (EULAs) for Microsoft and Fujitsu.



If you reject the terms of the license agreement you will be asked to review the license agreement for information on returning Windows® or to shut down your tablet.

You cannot use your tablet, until you have accepted the license agreement. If you stop the process your tablet will return to the beginning of the Windows® Welcome Process, even if you shut your tablet down and start it up again.

6. Connect to the Internet or Network

- Move the Wireless On/Off switch to on. After you have configured your computer, you can connect

to an active network by clicking on the Wireless Network icon in the system tray

- Register your STYLISTIC Q702 with Fujitsu Service and Support via our website (<http://solutions.us.fujitsu.com/www/content/support/>). This helps us to better serve you.

7. Activate Additional Utilities, Applications, & Drivers

- You can launch desktop icon "Fujitsu Bonus Apps" to see if there are any additional applications available for the system. Bonus Apps contains optional applications. You can select individual or all software that is available. BonusApps will automatically install for you.

8. Calibrating the Display

In order to ensure accurate tracking between the stylus and cursor, you must run the Calibration Utility before you use the system for the first time, or after you change the display resolution.

To run the calibration utility:

- Go to Start -> Control Panel.
- Double-click the Tablet Settings icon and select the Display tab
- Click the [Calibrate] button, then select whether you want to calibrate pen input or touch input.
- Adjust the display of your tablet to a comfortable angle and find the (+) symbol in the upper-left corner of the display.



DO NOT USE EXCESSIVE FORCE WHEN TAPPING ON THE SCREEN DURING CALIBRATION. USE OF EXCESSIVE FORCE COULD RESULT IN DAMAGE TO THE LED AND/OR TOUCH PANEL

- Using the stylus or your finger (depending upon which type of input you are calibrating), firmly touch the screen directly on the (+) symbol. Lift the stylus from the screen and the target will move to a different location on the screen.
- Repeat the previous step until you have selected all of the (+) symbols.
- Once you have selected all the symbols, press the [OK] button.
- Touch the stylus to various points on the screen to verify that the screen is correctly calibrated. If you are not satisfied with the screen's calibration, press the [Calibrate] button to begin again.

9. Create backup media with MyRecovery

- Click on the [MyRecovery] icon to create backup recovery media discs. (You will need to use an external optical drive.)
- Look in the User's Guide (Troubleshooting Your STYLISTIC Q702) for more detailed instructions.



10. User's Guide

- Your electronic User's Guide contains important detailed information about your new computer. You can access your User's Guide by selecting its icon from the screen desktop. (You will need to be connected to the Internet.)

Common Indicators

Status Display Panel

The indicators are only visible when the unit is on.



Quick Tips

It takes approximately 3 hours to charge a fully discharged single battery with unit off or in suspend mode.

Optimizing Battery Life

- Set power management setting for best battery life.
- Adjust display brightness levels to lowest comfortable setting.
- Utilize Suspend mode when not using your tablet.
- Read the Power Management section in your User's Guide for additional features.

Heat damage to your Lithium ion battery

- Extended exposure to heat will have a negative impact on your battery. Do not expose your tablet to excessive heat such as leaving it in the car on a hot summer day. If you are near an outlet and playing a graphics-intensive game, it is recommended that you remove the battery from the unit to avoid exposing it to excessive heat.

Discharging your battery

- Full battery discharges (to unit shutdown or 0%) should be avoided. It is recommended that batteries only be partially discharged to levels of 20-30% before recharging.

Prolonged storage

- If your tablet isn't going to be used for a while, you should remove its Lithium ion battery. To store a battery for long periods of time, its charge capacity should be around 40% and store it in a cool dry place.

Purchasing a replacement battery

- Only purchase a replacement battery from Fujitsu. Ensure that you purchase a battery that is specifically designed for your model computer. It is recommended that you purchase a replacement battery only when the current battery has noticeably degraded; unused batteries will still suffer degradation when stored.


Button Name	Primary Function (Press)	Description for Rotation and Windows Buttons
Volume Down Button	Volume Down	When you press and hold the Rotation Button, the autorotation feature is turned off or turned on, depending on its previous state.
Volume UP Button	Volume Up	
Rotation Button	Rotate Lock	If you press the Rotation button while the Fujitsu logo appears during system boot, the BIOS Setup Utility will open. While you are in the BIOS Setup utility, the Volume up button functions as a up arrow key and volume down button functions as a down arrow key.
Windows Button	Quick access to the Start menu	When you press and hold the Windows button, then slide the power button, the CTRL+ALT+DEL screen is brought up.

Important Safety Instructions

This unit requires an AC adapter to operate. Use only UL Listed I. T.E. Adapters with an output rating of 19 VDC, with a current of 3.16A (60 W).

AC adapter output polarity: 


When using your Tablet PC, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

-  **CAUTION: HOT SURFACE:** THE BOTTOM OF THIS COMPUTER CAN BECOME HOT WHEN USED FOR LONG PERIODS OF TIME. WHEN USING THIS DEVICE, TAKE CAUTION TO LIMIT LONG TERM OR CONTINUOUS USE WHILE RESTING IT ON EXPOSED SKIN, SUCH AS THE LAP.
- CAUTION: RISK OF EXPLOSION OF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.**


- Do not use this product near water for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Uses only the power cord and batteries indicated in the User's Guide for this product. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

Save These Instructions

For Authorized Repair Technicians Only

-  DANGER OF EXPLOSION IF LITHIUM (CLOCK) BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISPOSE OF USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTION.

-  FOR CONTINUED PROTECTION AGAINST RISK OF FIRE, REPLACE ONLY WITH THE SAME TYPE AND RATING FUSE.



Popular Accessories

Additional Main Lithium Polymer Battery
(For optional Keyboard docking station)

Auto/Airline Power Adapter

Additional AC Adapter

Carrying Cases

STYLISTIC Q572 Tablet PC Cradle

Have questions or need help?

- Visit our website at solutions.us.fujitsu.com
- Call us anytime at 1.800.8FUJITSU
- Email us at 8fujitsu@us.fujitsu.com

Want more information on Fujitsu products?

- Visit our website at www.shopfujitsu.com
- Call us anytime at 1.800.FUJITSU

Fujitsu Extended Service Plans available.

Visit us.fujitsu.com/computers

to purchase any of these accessories
or to get more information.

Record your tablet serial number here:

Serial # _____
(see bottom of computer)

Fujitsu America, Inc.
1250 E. Arques Avenue
Sunnyvale, CA 94085

Fujitsu, the Fujitsu logo, and STYLISTIC are registered trademarks of Fujitsu Limited. Microsoft and Windows are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. All other trademarks mentioned herein are the property of their respective owners. Product description data represents Fujitsu design objectives and is provided for comparative purposes; actual results may vary based on a variety of factors. Specifications are subject to change without notice.

©2012 Fujitsu America, Inc. All rights reserved.



B5FK-0121-01EN-00